

The original red flexible tube 70/100 and 125

Function:

The flexible tube for all standard ventilation systems. The free end of the hose is pushed onto the lower end of the ventilator duct and fixed in place with the pre-assembled hose clamp. The connection sleeve is pushed into the underlying connection piece on the ventilation duct. Check that the lip seal inserted is properly seated in the connection piece during installation. Socket position when installed on an incline with a min. of 45°.

Versions:

- 70/100 flexible hose for connection to DN 70 or DN 100 ventilation lines
- 125 flexible hose for connection to DN 70 ventilation line
- Hose length: type 70/100 500 mm; type 125 600 mm



