

The original red flexible tube 70/100 and 125

Function:

The flexible hose for all commercially available ventilation systems. The free end of the hose is slid onto the lower pipe end of the vent pipe and fixed with the pre-assembled hose clamp. The connection sleeve is inserted into the underlying connection piece of the ventilation pipe. Ensure correct placement of the inserted lip seal in the connection piece during installation. The sleeve position, when installed, should be inclined with a slope of at least 45°.

Versions:

- Flexible hose 70/100 for connection to ventilation pipes DN 70 or DN 100
- Flexible hose 125 for connection to ventilation pipe DN 70
- Hose lengths: Variant 70/100 500 mm; Variant 125 600 mm
- All flexible hoses are UV-resistant by default

